

Hardware Installation Guide for your BuzzLitePhone

Installation Steps

Installation is very easy but you might find it even easier to print this out and consult it as you work. It might look complicated but will take you about five minutes



Step one: Plug in the BuzzLitePhone

Plug the BuzzLitePhone into the USB port of the PC

Step two: Download the drive installation program

Go to www.buzz.bm/BLPSetup_V2.exe and download the latest version of the software. When asked if you want to Save or Run, click on Run. Go to 'Next' then 'Set up instructions for your LCD screen'. This will start by running the set up programme to enable you to use the keys on your keypad and will activate the LCD screen. This programme will put a shortcut on your desktop.



If the shortcut does not appear on your screen, go to the folder on your hard drive called "@Phone", open it and right click on "@phone.exe" Select "Send to desktop (create shortcut)" and this will put the icon on your desktop.

Any time that you reboot your computer and the LCD screen on the handset is not active, click on that icon to activate it.

Step three: Install the dialer software

You will have to go online to your chosen VoIP service provider (such as Skype – www.Skype.com) to download your software. Features of the BuzzLitePhone work with most, but not all, softphones.



Step four: Start calling!!